

# TruWood™ Premium Timber

**68"-80", TruWood Premium Timber Kit, Large**

Part Number:  
**TWL-68/80-SP-AU**

## **INSTALLATION GUIDE**

TruWood Premium Timber Kit models:  
LPM-6816V2, OR76-MULTI, LPM-8016V2.

TruWood Premium Timber Kit includes:

- Large logs (5)
- Slim logs (9)
- Bag of wood chips

# Assembly order

You will need to gain access to the ember bed of your fireplace. Refer to your fireplace manual for instructions for removing the front glass to access the ember bed.

Please Note: This kit is designed to fit multiple fireplace sizes. Your log set might be more spread out for longer fireplaces or more compact for the shorter fireplaces. If your fireplace is one of the smaller units this kit is compatible with, you may not need to use all the logs based on the available space of your fireplace.

The placement is what we recommend and what we optimized the set to, but you can have fun with them and place them to your liking.

1. Ensure the ember bed media (crystals, etc.) that came with the fireplace is installed first. If updating an existing fireplace, remove the old logs to accommodate the TruWood logs. Then select one of the large logs from the kit and place it in the middle of the fireplace. This will be the base of the TruWood log layout.



2. Select two large logs and rest them on the left and right of the first log. These are now creating the main portion of your stack. Spreading these out more for linear shaped fireplaces and bringing these closer together for traditional shaped fireplaces.



# Assembly order

3. Select two large logs, and stack these on the ends of the large logs.



4. Select two slim logs and lay them under the large logs. The inside end of the log may be towards you and the outer-side end may be towards the flame screen.



# Assembly order

5. Select two slim logs, and lay them under the large logs previously stacked, crossing directions where possible.



6. Select two slim logs in your kit, and lay these over the other slim logs.





# Assembly order

7. Select a slim log and lay it across the main log diagonally.



8. Select two slim logs in your kit, and stack these laying over the slim logs.



# Assembly order

9. Use the bag of wood chips and place a few chips and chunks in the gaps between the logs. We recommend using these sparingly for the best appearance and to maximize the light output from the ember bed.



68"-80", TruWood Premium Timber Kit, Large installation is complete.



**Thank you for choosing Modern Flames, we appreciate all our customers and hope you have many years of enjoyment of our products.**

07 5630 6840

| [info@modernflames.com.au](mailto:info@modernflames.com.au)

| [modernflames.com.au](http://modernflames.com.au)